

# DEM-4M1D

## Single Phase Energy Meter



**Version: 1.10**

**Revision: 2024.12**

## Read me

**When you use DEM-4M1D single phase energy meter, be sure to read this user manual carefully, and be able to fully understand the implications, the correct guidance of operations in accordance with user manual, which will help you make better use of DEM-4M1D single phase energy meter, and help to solve the various problems at the scene.**

1. Before the meter turning on the power supply, be sure that the power supply within the provisions of the instrument;
2. When installation, the current input terminal must non-open, voltage input terminals must Non-short circuit;
3. Communication terminal (RS232/RS485) is strictly prohibited to impose on high pressure;
4. Be sure the instrument wiring consistent with the internal system settings;
5. When communicating with the PC, instrument communication parameters must be consistent with the PC.



- **Please read this user manual carefully**
- **Please save this document**

## Directory

<b>1. - SUMMARIZE .....</b>	<b>- 3 -</b>
<b>2. - TECHNICAL PARAMETERS .....</b>	<b>- 4 -</b>
<b>3. - INSTALLATION AND START-UP .....</b>	<b>- 5 -</b>
3.1.- INSTALLATION .....	- 5 -
3.2.- CONNECTION TERMINAL .....	- 7 -
3.3.- TYPICAL WIRING .....	- 8 -
<b>4. - SCREEN DISPLAY .....</b>	<b>- 9 -</b>
4.1.- SCREEN DESCRIPTION: .....	- 9 -
4.2.- INDICATOR LIGHT DESCRIPTION: .....	- 9 -
4.3.- SCREEN PAGES DESCRIPTION: .....	- 10 -
<b>5.- OPERATION MENU DESCRIPTION .....</b>	<b>- 11 -</b>
5.1.- BUTTON DESCRIPTION .....	- 11 -
5.2.- MAIN MENU .....	- 11 -
5.2.1.- Detail information of menu .....	- 12 -
5.3.- DESCRIPTION OF MENU CHARACTERS: .....	- 14 -
<b>6.- PULSE OUTPUT .....</b>	<b>- 16 -</b>
<b>7 - COMMUNICATION INTERFACE .....</b>	<b>- 17 -</b>
7.1.- CONNECTION FOR RS485 BUS .....	- 17 -
7.2.- MODBUS ® PROTOCOL .....	- 18 -
7.3.- REGISTER MAP .....	- 19 -
7.4.- EXAMPLE .....	- 23 -
<b>8. - SAFETY CONSIDERATIONS .....</b>	<b>- 24 -</b>
<b>9. - MAINTENANCE .....</b>	<b>- 24 -</b>
<b>10. - TECHNICAL SERVICE .....</b>	<b>- 25 -</b>

## 1. - SUMMARIZE

Single-phase rail-type electric energy meter is an intelligent device used in medium and low voltage systems (6-35KV and 0.4KV). It integrates data acquisition and control functions, adopts segment code LCD screen, and has single-phase AC power measurement and calculation. Energy accumulation, RS485 communication and other functions.

DEM-4M1D single phase energy meter is 4M width single phase din rail energy meter, maximum load can directly have connected to 80A current. Built-in interfaces provide pulse and RS485 Modbus RTU outputs. Optional prepaid metered version, wireless communication version.

### FEATURES

- 10(80)A direct access, 0.04A start current;
- Din-rail mounting 35mm, 4 module width size;
- Measures and display KWh Kvarh, KW, PF, HZ, V, A, etc;
- Provide energy import and export measurement (IMP & EXP);
- Current & voltage accuracy is 0.5s%;
- Active accuracy is class 1.0;
- Reactive energy accuracy is class 2.0;
- With 1\* energy pulse output;
- With 1\* RS485 port;
- Optional multi-tariff record, max demand and other parameters;
- Optional built-in latching relay for remote control;
- Optional internal wireless module for various communication;

### APPLICATIONS

- All power parameter measurement;
- Energy measurement and electrical fire monitor and control;
- Transformers, generators, capacitors and electric motors distributed detection;
- Medium and low voltage systems;
- SCADA, EMS, DCS integrators.

## 2. - TECHNICAL PARAMETERS

### Measurement & Display

Voltage	Rated 220V RMS value, Accuracy 0.5s%,
Current	0.04-10(80)A, Direct access
Active energy accuracy	Class 1.0, IEC 62053-22
Reactive energy accuracy	Class 2.0, IEC 62053-23
Current overload	Measurement: 1.2 times, Instantaneous: 10 times/1s
Voltage overload	Measurement: 1.2 times, Instantaneous: 2 times/10s
Consumption	<0.4VA(per phase)
Frequency	40-65Hz, Accuracy $\pm 0.01$ Hz
Display	LCD with white backlit
Maximum display value	99,999,999KWh
AUX Power	90-240V AC, <2W/10VA

### Other parameters

Communication	1 channels RS485, Modbus RTU
Pulse output port	1 channels pulse output, 1600imp/kWh
Multi- tariffs records	3 months energy data record, 4 set rates, 12 segment (optional function)
Working environment	-10~55°C      Altitude $\leq 2000$ m,      0~93%RH, non-condensing, non-corrosive gas
Storage environment	-30~70°C
Voltage tolerance	2KV 1min
Insulation	Input, output, power supply to Shell >5M $\Omega$

### 3. - INSTALLATION AND START-UP



The manual you hold in your hand contains information and warnings that the user should respect in order to guarantee a proper operation of all the instrument functions and keep it in safety conditions. The instrument must not be powered on and used until its definitive assembly is on the cabinet's door.


**If the instrument is not used as manufacturer's specifications, the protection of the instrument will be damaged.**



When any protection failure is suspected to exist (for example, it presents external visible damages), the instrument must be immediately powered off. In this case contact a qualified service representative.

#### 3.1.- Installation

##### Mounting

Instrument is to be mounted on 35mm Din-rail. Keep all connections into the cabinet. Please note that with the instrument powered on, the terminals could be dangerous to touch and cover opening actions or elements removal may allow accessing dangerous parts. Therefore, the instrument must not be used until this is completely installed.



**Dimension:**
**Unit: mm**

**Front view**

**Side view**
**Notes:**

Input signal: DEM-4M1D using a separate acquisition calculate for each measurement channel, to ensure consistent in use, for different load forms, it's a variety of connection mode. Access wire shall be met 3 square mm.

**A. Voltage input**

Input voltage should not exceed the rated input voltage products 450V.  
 Otherwise, you should use external VT. Suggest 1A fuse be installed in the voltage input side.

**B. Current Input**

The meter adopts a direct connection type current input design, supporting rated current ranges of 0.04-10(80)A. The current is measured by directly passing the load current through the meter's internal current path, eliminating the need for external current transformers (CTs).

**C. Auxiliary power**

DEM-4M1D with universal (AC / DC) power input, if not for a special statement, we provide the 90-240AC/DC power interface for standard products, please ensure that the auxiliary power can match with meter to prevent unexpected damage.

A. Suggest install 1A fuse in the fire line side.

B. For the areas with poor power quality, suggest install lightning surge suppressor and rapid burst suppressor to prevent lightning strikes.

### 3.2.- Connection Terminal

5	6	7	8	9	10
RS485				+	-

5-6: RS485-1 A, B

9-10: Active energy pulse output (+/-)

4	3	2	1
		N	L

1-2: Auxiliary power supply +/-

**Note:**

The terminal pin definition may change depends on customer order, please refer to the label on the meter!



### 3.3.- Typical Wiring



#### Note:

This connection drawing is for reference only; the actual connecting terminal please refer to the label on the rear part.

#### WARNINGS!

If power = -0.01 is shown for any of the phases and voltage and current are not zero for this phase, check out following points:


- Assure that A, B and C phases coincide in voltage and current.
- Correct polarity? Reverse the current transformer placed at this phase.

## 4. - SCREEN DISPLAY



### 4.1.- Screen description:

#### Panel introduction










- 1.- Display measurement data
- 2.- Pulse output LED indicator
- 3.- Key Button



### 4.2.- Indicator light description:



Name	Function definition (when lighting)
	Active energy pulse output
	Active power reverse

#### 4.3.- Screen pages description:




Screen No.	Screen interface	Description
1		Total positive active power
2		Total negative active power
3		Total positive reactive power
4		Total negative reactive power
5		Active energy for multi tariff function (optional) Press  to view details data
6		Max demand function (optional) Press  to view details data
7		Voltage and other parameters

## 5.- OPERATION MENU DESCRIPTION


### 5.1.- Button description


	<p><b>Short press</b> is the left key to switch the measurement screen;</p> <p><b>Long press</b> is the menu key to call out password screen and enter/ exit setting menu;</p>
	<p><b>Short press</b> is the right key to switch the measurement screen;</p> <p><b>Long press</b> is the confirmation key to enter password 0001, and when exit setting menu to save the modified data.</p>

### 5.2.- Main menu

In the case of measuring data, long press the " " key, and a prompt of "PASS" (that is, "password") will appear, short press the " " key to enter the user-level password (the default is 0001), and long press the " " key to enter programming. In the status, the instrument provides three types of input setting menu items: system factory commissioning (SYS), input (-IN-), communication (bus), and multi tariff (time), meter reading day (E.day), rate (E.SEG) and other additional setting menu items. Adopt LCD display layered menu structure management.

### 5.2.1.- Detail information of menu



**Time of use/multi-tariff setting:**


### 5.3.- Description of menu characters:

<b>PASS</b>	(Password) User password
<b>Erro</b>	(Error) Wrong input information
<b>-I n-</b>	(Input) User Display data settings menu
<b>bUS</b>	(Bus) Communication settings menu
<b>SYS</b>	(System) System settings menu (for factory debugging, not open yet)
<b>Code</b>	(Code) Enter password
<b>dAtA</b>	(Data) Communication parameter setting
<b>Addr</b>	(Address) Local communication address setting
<b>bAUd</b>	(Baud) Communication baud rate
<b>oB 1</b>	(o.8.1) Indicates 8 data bits, 1 stop bit, odd parity
<b>EB 1</b>	(e.8.1) Indicates 8 data bits, 1 stop bit, even parity
<b>nB 1</b>	(n.8.1) Indicates 8 data bits, 1 stop bit, no parity bit
<b>USCL</b>	(U.scl) Select rated input voltage
<b>ISCL</b>	(I.scl) Select rated input current
<b>r. Ct</b>	(R.ct) Set the current multiplier
<b>r. Pt</b>	(R.pt) Set voltage ratio
<b>SYS</b>	(System) System settings menu (for factory debugging, not open yet)
<b>TYPE</b>	(Type) What parameters to set

<b>PARr</b>	(Para Corresponding parameter selection
<b>VALU</b>	(Value) Set the corresponding alarm value
<b>Code</b>	(Code) Modify password value
<b>YEARr</b>	(Year) Set year
<b>mon</b>	(Month) Set month
<b>DAY</b>	(Day) Set day
<b>DATE</b>	(Date) Set date
<b>Hour</b>	(Hour) Set hour
<b>min</b>	(Min.) Set minute
<b>SEC</b>	(Second) Set second
<b>ESEC</b>	(Seg.) Set segment
<b>Emod</b>	Rate
<b>FLAt</b>	Flat
<b>LoV</b>	Valley
<b>ti nE</b>	Sharp
<b>PERt</b>	Peak
<b>EdRY</b>	Meter reading time setting



## 6.- PULSE OUTPUT

DEM-4M1D provides 1\* pulse output for active energy.

The host / PLC / DI module can cumulative the data of both the active and reactive power energy sent by the pulse from opt coupler relay.

1). Electrical specification: voltage  $VCC \leq 48V$ ,  $I_z \leq 50mA$ .

2). Pulse: 5000 imp / kWh, pulse up to 80ms.

This means: When the device detects 1 kWh, the port will generate 5000 pulse

### Note:

1 kWh energy is for secondary side energy data, if there have PT and CT accessed; primary side energy data is "1 kWh  $\times$  PT ratio  $\times$  CT ratio".

Voltage (V)	Current (A)	Pulse constant (imp / kWh)
380 or 220	5	5000
	1	20000
100	5	20000
	1	80000


Example: In measure time "T", the received total pulse is "N",  
Primary side input of voltage is 10Kv  
Primary side input of current is 400A.  
Secondary side measurement range is 100V and 5A.

In the time "T", energy accumulated is:  $N / 20000 \times 100 \times 80$

## 7 - COMMUNICATION INTERFACE

### 7.1.- Connection for RS485 BUS

The composition of the RS-485 cabling must be carried out with a meshed screen cable (minimum 3 wire), diameter of not less than 0.5mm<sup>2</sup>, with a maximum distance of 1,200 m between the DEM-4M1D... and the master unit. This Bus may connect a maximum of 32pcs.



#### Notes:

- For communication with the master unit, user can choose RS-485 to RS-232 converter or RS485 to USB adapter to use.
- For expand the number of devices in the communication network, a signal repeater can be used.
- Due to product modifications or special requirements, the interface pin place may be change. For details, please refer to product label on the rear side

## 7.2.- MODBUS © Protocol

### Modbus RTU Frame Format:

<b>Address code</b>	<b>1 BYTE</b>	<i>Slave device address 1-247</i>
<b>Function code</b>	<b>1 BYTE</b>	<i>Indicates the function codes like read coils / inputs</i>
<b>Data code</b>	<b>4 BYTE</b>	<i>Starting address, high byte Starting address, low byte Number of registers, high byte Number of registers, low byte</i>
<b>Error Check code</b>	<b>2 BYTE</b>	<i>Cyclical Redundancy Check (CRC)</i>

### MODBUS FUNCTIONS:

<b>Code</b>	<b>Meaning</b>	<b>Description</b>
<b>FUNCTION 01</b>	Read Coil Status	<i>Only valid when equipped DO port</i>
<b>FUNCTION 02</b>	Read Input Status	<i>Only valid when equipped DI port</i>
<b>FUNCTION 03</b>	Reading of n Words	<i>This function permits to read all the electrical parameters</i>
<b>FUNCTION 05</b>	Force Single coil	<i>When DO in remote control mode can work</i>
		<b>Disable in default</b>
<b>FUNCTION 06</b>	Preset Single register	<i>If need valid this code, please contact Blue Jay Sales Team before your order!</i>

**Note:** Float data follow **IEEE754**, float low bit first, high bit next. **(CD AB)**

### 7.3.- Register Map

#### 7.3.1.- Basic power data-Primary Side

Register	Data	Byte mode		Instruction
0x00	U	float	2	Phase to Line Voltage, Unit: V
0x0c	I	float	2	Current, Unit: A
0x12	P	float	2	Active power, Unit: kw
0x1a	Q	float	2	Reactive power, Unit: kvar
0x22	S	float	2	Apparent power, Unit: kva
0x2a	PF	float	2	Power factor, 0~1.000
0x32	FR	float	2	Frequency, Unit:0.01Hz
0x34	Ep+	float	2	Positive active energy, Unit: kWh
0x36	Ep-	float	2	Negative active energy, Unit: kWh
0x38	Eq+	float	2	Inductive reactive power, Unit: kVarh
0x3a	Eq-	float	2	Capacitive reactive power

### 7.3.2.- Basic power data-Secondary Side

Register	Data	Byte mode		Instruction
0x100	Ua	int	1	Voltage, Unit: 0.1V Current, Unit:0.001 A
0x106	Ia	int	1	
0x109	Pa	int	1	Active power, Unit: W
0x10d	Qa	int	1	Reactive power, Unit: Var
0x111	Sa	int	1	Apparent power, Unit: Va
0x115	PFa	int	1	Power factor, 0~1.000
0x119	FR	int	1	Frequency, unit:0.01hz
0x11a	Ep+	int	2	Positive active energy, Unit: Wh
0x11c	Ep-	int	2	Negative active energy, Unit: Wh
0x11e	Eq+	int	2	Inductive reactive power, Unit: Varh
0x120	Eq-	int	2	Capacitive reactive power

### 7.3.3.- Advanced electrical parameter (optional function)

Register	Data	Byte mode		Instruction
0x300	Pde	float	2	Present active power demand, Unit: W
0x302	Qde	float	2	Present reactive power demand, Unit: var
0x304	Sde	float	2	Present apparent power demand, Unit: VA
0x306	PzM1	float	2	Active power demand in present month
0x308	QzM1	float	2	Reactive power demand in present month
0x30a	SzM1	float	2	Apparent power demand in present month
0x30c	PzM2	float	2	Active power demand in last month
0x30e	QzM2	float	2	Reactive power demand in last month
0x310	SzM2	float	2	Apparent power demand in last month
0x312	PzM3	float	2	Active power demand in month before last month
0x314	QzM3	float	2	Reactive power demand in month before last month
0x316	SzM3	float	2	Apparent power demand in month before last month
0x318-0x31F		float	2	Reversed

### 7.3.4.- Multi- tariffs ratio data (optional function)

Register	Data	Byte mode		Instruction
0x400	E0_tol	long	2	Total cumulative energy
0x402	E0_T1	long	2	T1-T4 cumulative Energy record
0x404	E0_T2	long	2	
0x406	E0_T3	long	2	
0x408	E0_T4	long	2	
0x40a	E1_tol	long	2	Total energy of present month
0x40c	E1_T1	long	2	T1-T4 Energy record of present month
0x40e	E1_T2	long	2	
0x410	E1_T3	long	2	
0x412	E1_T4	long	2	
0x414	E2_tol	long	2	Total energy of last month
0x416	E2_T1	long	2	T1-T4 Energy record of last month
0x418	E2_T2	long	2	
0x41a	E2_T3	long	2	
0x41c	E2_T4	long	2	
0x41e	E3_tol	long	2	Total energy of the month before last month
0x420	E3_T1	long	2	T1-T4 Energy record the month before last month
0x422	E3_T2	long	2	
0x424	E3_T3	long	2	
0x426	E3_T4	long	2	

Notes:

1. The data can be read out depends on your multi-function meter model, please refer to the corresponding product manual before build your software.
2. Some software has different definitions of the start bit of register address, there will be offset, please add 1 for the right address. To get more info, please contact technical support.

## 7.4.- Example

Host inquiry slave device

Addr	Func	Data Address high	Data Address low	Data Number high	Data number low	CRC16 low	CRC16 high
0CH	03H	00H	00H	00H	06H	C4H	D5H

**PC user ask upload UA, UB, UC, IA, IB, IC**

Slave device response

Addr.	Func.	Byte count	Data1 high	Data1 low	Data2 high	Data2 low	Data3 high	Data3 low
0CH	03H	0CH	03H	E8H	03H	E9H	03H	E8H
Data4 high	Data4 low	Data5 high	Data5 low	Data6 high	Data6 low	CRC16 low	CRC16 high	
13H	84H	13H	88H	13H	8AH	A6H	D6H	

**Show the data:**

UA=3E8H (100.0)

UB=3E9H (100.1)

UC=3E7H (99.9)

IA=1384H (4.996)

IB=1388H (5.000)

IC=138AH (5.002)

### Notes:

1. Blue Jay disable the 06 function in default setting, if Activated the write command, please check the host device program to avoid the meaningless write operation, that may reduce the reduce the register working life.
2. When the write is unsuccessful, no return data from the slave device. In this addition, please re-send write inquiry again.



## 8. - SAFETY CONSIDERATIONS



All installation specification described at the previous chapters named:  
**INSTALLATION AND STARTUP, INSTALLATION MODES and SPECIFICATIONS.**

Please note that with the instrument powered on, the terminals could be dangerous to touching and cover opening actions or elements removal may allow accessing dangerous parts. This instrument is factory-shipped at proper operation condition.

- ◆ The device must have a professional installation and maintenance
- ◆ Any operation of the device, you must cut off the input signal and power;

## 9. - MAINTENANCE

The DEM-4M1D single phase energy meter does not require any special maintenance. No adjustment, maintenance or repairing action should be done when the instrument is open and powered on, should those actions are essential, high-qualified operators must perform them.

Before any adjustment, replacement, maintenance or repairing operation is carried out, the instrument must be disconnected from any power supply source.

When any protection failure is suspected to exist, the instrument must be immediately put out of service. The instrument's design allows a quick replacement in case of any failure.

## 10. - TECHNICAL SERVICE

### FAQ's

- 1.-** Once cabled and connected is seen to give a correct voltage and current reading, but shows negative values for active power (generation).

This is an error with the cabling for the current transformer secondary; the direction of the transformer current has to be respected as shown in the connection diagram. The current transformers have a two face primary; the current must pass from P1 to P2 giving the result in secondary (S1 and S2) of 5 amps.

The error stems from:

- a).** The current transformers have been incorrectly installed. As a result, it gives the direction of the current as passing from P2 to P1; to resolve this problem, the current transformer does not have to be dismantled and installed again, but the transformer secondary (S1 and S2) just has to be inverted.
  - b).** The connection of the current secondary in the current transformers have been incorrectly connected; to resolve this problem just connect the S1 transformer secondary to the S1 on the meter and the S2 on the current transformer to the S2 on the meter.
- 2.-** Once cabled and connected, is seen to give an incoherent Power factor and Cos $\Phi$  reading (-0.01 or similar).

This is again a current transformer and voltage phase connection error phase A, must correspond to the current transformer installed in phase A; phase B, must correspond to the current transformer installed in phase B; and phase C, must correspond to the current transformer installed in phase C.

This connection terminal is clearly shown on the area side of the device.

- 3.-** The measuring voltage and is displaying the secondary voltage (for example 110 volts).  
Ensure that the voltage Transformer ratio has been correctly set.
- 4.-** Device does not correctly display the current reading. It shows values varying between 0 to 5 amps of current.  
Ensure that the Current Transformer ratio has been correctly set.

## Calculation formula of electrical parameter

Formula	Parameter
$U = \sqrt{\frac{1}{N} \sum_{n=0}^N u_n^2} \quad n = 0, 1, 2, \dots, N$	Voltage RMS value
$I = \sqrt{\frac{1}{N} \sum_{n=0}^N i_n^2} \quad n = 0, 1, 2, \dots, N$	Current RMS value
$P = \frac{1}{N} \sum_{n=1}^N (i_{an} u_{an} + i_{bn} u_{bn} + i_{cn} u_{cn})$	Total active power cycle average
$P_s = UI$	Single-phase apparent power cycle average
$\cos \theta = \frac{P_p}{P_s}$	Power factor
$P_q = \sqrt{P_s^2 - P_p^2}$	Reactive power (Pq is positive and the direction cannot be determined; P algorithm can be used to shift the voltage component by 90°)
$W = \int P * dt$	Electric energy

**Note:** In above formula, N for sampling points in one AC wave.

For any inquiry about the instrument performance or any failure, contact to Blue Jay's technical service.

*Blue Jay - After-sales service*

E-mail: [tech@cqbluejay.com](mailto:tech@cqbluejay.com)