

# AFR-4

## Arc Flash Protection Relay

### User Manual



**Version: 1.11**

**Revision: 2025.02**

## Read me

**When you use AFR-4, be sure to read this user manual carefully, and be able to fully understand the implications, the correct guidance of operations in accordance with user manual, which will help you make better use of arc protection device, and help to solve the various problems at the scene.**

1. This product must be earthed reliably.
2. Do not drop this product during installation to avoid damage to this product.
3. The terminal blocks must be connected firmly to avoid serious consequences caused by dropping.
4. Please do not plug or unplug the circuit board during the normal operation of this product; otherwise, the data of this product will be lost and the product may not operate normally.
5. The rated value is not changed randomly and it can be only changed by relevant professionals.
6. When installing, please install this product according to the terminal definition, and do not wire randomly.
7. After installation and energizing, do not touch the exposed terminals and the bare parts of the power supply and do not place this product in a damp area to avoid leakage and short circuit at the terminals.



- **Please read this user manual carefully**
- **Please save this document**

## Directory

<b>1.- SUMMARIZE .....</b>	<b>- 3 -</b>
<b>2.- SPECIFICATION .....</b>	<b>- 4 -</b>
<b>3.- ARC SENSOR INTRODUCTION .....</b>	<b>- 5 -</b>
<b>4.- DIP SWITCH FUNCTION DESCRIPTION .....</b>	<b>- 7 -</b>
4.1.- FUNCTION ON/OFF SETTING INTRODUCTION .....	- 7 -
4.1.1.- SW01: Switch between ARC protection mode 1/ mode2 .....	- 8 -
4.1.2.- SW02: Turn ON/OFF master trip mode .....	- 11 -
4.1.3.- SW03: Turn ON/OFF alarm function .....	- 13 -
4.1.4.- SW04: Turn ON/OFF overcurrent judgment .....	- 13 -
4.1.5.- SW05-08: Turn ON/OFF ARC01-04 sensor .....	- 13 -
4.2.- RS485 COMMUNICATION SETTING .....	- 14 -
<b>5.- INSTALLATION AND START-UP .....</b>	<b>- 15 -</b>
5.1.- DIMENSION .....	- 15 -
5.2.- TERMINAL DEFINITION .....	- 16 -
5.3.- INDICATOR DESCRIPTION .....	- 17 -
<b>6.- COMMUNICATION INTERFACE .....</b>	<b>- 18 -</b>
6.1.- MODBUS © PROTOCOL .....	- 18 -
6.2.- REGISTER MAP .....	- 19 -
6.2.1.- Read DI signal, Read only, "02H" code to read .....	- 19 -
6.2.2.- Parameter query, Read only, "03H" code to read .....	- 21 -
6.2.3.- Basic parameter, Read only, "04H" code to read .....	- 23 -
6.2.4.- DO control, write only, "05H" code to write .....	- 24 -
6.2.5.- DI signal reset, write only, "06H" code to write .....	- 25 -
6.2.6.- Parameter modification, Write only, "10H" code to write .....	- 26 -
6.2.7.- Restore factory settings, Write only, "13H" code to write .....	- 27 -
<b>7.- SAFETY CONSIDERATIONS .....</b>	<b>- 28 -</b>
<b>8.- MAINTENANCE .....</b>	<b>- 28 -</b>

## 1.- SUMMARIZE

AFR-4 is a versatile and independently operating device for bay based protection. It supports 4-channels arc signal detection and can configuration multiple arc tripping modes, ensuring accurate and fast fault isolation. With a fast relay output speed up to 4ms, AFR-4 can minimize or completely eliminate arc flash damage, improving system safety and reliability. It can be used in various arc protection applications in low or medium voltage power distribution system.

AFR-4 also provides flash warning and dual criteria tripping mechanism (arc detection + current), providing a comprehensive solution for arc flash protection. Integrated RS485/Modbus communication enables seamless remote monitoring and control, which is ideal for modern power systems.

### FEATURES

- $\leq 4$ ms fast relay tripping;
- Regional arc light detection;
- Multiple combined tripping modes;
- Circuit breaker failure protection;
- 4 channels of arc light signals detection;
- Dual criteria for arc detection and overcurrent detection;
- Integrated /RS485 MODBUS communication protocol;
- Support ST visible light and ST ultraviolet sensor access.

### APPLICATIONS

- Power substations;
- Box-type substations;
- Water conservancy projects;
- Electrical switchgear for thermal power plants;
- Switchgear for wind farms and photovoltaic stations;
- Large-scale municipal engineering projects.

## 2.- SPECIFICATION


<b>Working power supply</b>	
Power supply	AC/DC 85~265V
Power consumption	≤8W
<b>Current input</b>	
Rated current value	5A/1A
Measuring range	Protection current: 0.6~6In
Error	≤4%
<b>Arc signal input</b>	
Number of channels	4 channels
Sensor type	ST optical fiber type
Detection light type	Visible/ UV optional
Spectrum	280-550nm
Optical threshold	8000 lux (±20%)
Optical fiber	5m/10m/15m
<b>Action time</b>	
Fast relay output	≤4ms
Pure arc trip	≤8ms
Current+ arc trip	≤15ms
<b>Relay output</b>	
Quantity	6 trip output
Operating Voltage	5A@250V
Input	Passive contact, photoelectric isolation, isolation voltage 2500V
Mechanical life	≥10000 times
<b>Communication Interface</b>	
Communication Interface	1 Channel, photoelectric isolation, with lightning protection
Baud rate	4800, 9600bps (default 9600),19200
Communication protocol	Modbus RTU
<b>Environment</b>	
Working temperature	-10 ~ +55°C
Storage temperature	-25 ~ +70°C
Humidity	5~95%RH
Atmospheric pressure	60kPa~106kPa

### 3.- ARC SENSOR INTRODUCTION


Arc sensors are optical sensing elements designed to detect arc faults. When an arc fault occurs, the light intensity increases significantly. The arc sensor converts this optical signal into an electrical signal and transmits it to the arc protection or arc extension unit for processing.

The arc light sensor is specifically designed based on the spectral characteristics of arc light. It utilizes specialized optical materials, polymer blending and doping technology, as well as advanced optical lens technology to effectively filter out interference from visible light. The ultraviolet arc light sensor probe can rapidly detect arc flashes within a coverage area of over 240 degrees. The detected signal is then transmitted to the control equipment via optical fiber, enabling fault isolation at the millisecond level to prevent severe consequences.


#### Arc light sensor dimension and hole size (Unit: mm)





#### Sensor installation diagram



Notes: Suggest open hole 2.8mm diameter on switchgear panel for M3 screw



Notes: Suggest open hole 2.8mm diameter on switchgear panel for M3 screw


**UV spectral response curve**

**Visible light spectrum response curve**
**Arc sensor specification:**

Sensor type	Visible light sensor	UV light sensor
Sensitivity type	Full spectrum	UV spectrum
Spectral response bandwidth	250nm ~ 550nm	280nm ~ 400nm
Monitoring angle	-120°~ 120°	-120°~ 120°
Angle decay rate	≤20%	≤10%
Operating temperature	-30~70°C	-40~85°C
Interface type	ST fiber optic/screw fixing	ST optical fiber
Optical fiber length	5/10/15 meters	5/10/15 meters

## 4.- DIP SWITCH FUNCTION DESCRIPTION



ARC protection function ON/OFF setting (Detail see [chapter 4.1](#)).



RS485 communication setting (Detail see [chapter 4.2](#)).

Note: the direction marked with "ON" represents: 1, and reverse direction marked with number represents: 0.

### 4.1.- Function ON/OFF setting introduction

By switching the ON/OFF DIP switch, you can set the protection mode, add current criteria, activate the arc sensor, and turn on the alarm function.

SW01	Mode	0-M1/1-M2
SW02	MT Mode	0-OFF/1-ON
SW03	Alarm	0-OFF/1-ON
SW04	I>Iset	0-OFF/1-ON
SW05	ARC01	0-OFF/1-ON
SW06	ARC02	0-OFF/1-ON
SW07	ARC03	0-OFF/1-ON
SW08	ARC04	0-OFF/1-ON

**SW01:** Switch between ARC protection mode 1/ mode2, detail see [chapter 4.1.1](#).

**SW02:** Turn ON/OFF master trip mode, detail see [chapter 4.1.2](#).

**SW03:** Turn ON/OFF alarm function, detail see [chapter 4.1.3](#).

**SW04:** Turn ON/OFF overcurrent judgment, detail see [chapter 4.1.4](#).


**SW05-08:** Turn ON/OFF ARC01-04 sensor, detail see [chapter 4.1.5](#).



**4.1.1.- SW01: Switch between ARC protection mode 1/ mode2**


**Mode 1: Local trip**

When any arc sensor detects arc signal, the device will trip FT, Trip1, Trip2 relay.



**Application example 1**


If the SW04 current judgment function is turn on, when an arc signal is generated and the overcurrent exceeds the set value, the FT, Trip1, and Trip2 relays will trip. If current is still detected and after a delay, the device will trip Trip3 and Trip4 to disconnect the circuit.



**Application example 2**

Trip3 and Trip4 can also be connected to external devices. When an arc signal is generated and the overcurrent exceeds the set value, the device will trip FT, Trip1 and Trip2 inside the cabinet.

If current is still detected and after a delay, Trip3 and Trip4 will be tripped to disconnect the circuit via external equipment. This function is typically used when the cabinet's circuit breaker fails to trip due to arc damage, ensuring that the external devices can trip to protect the switchgear.



Application example 3

Relay action diagram:


Mode	Sensor	Fast trip	Trip 1	Trip 2	Trip 3	Trip 4
Mode 1	ARC01	Act	Act	Act	Act (after delay)	Act (after delay)
	ARC02	Act	Act	Act	Act (after delay)	Act (after delay)
	ARC03	Act	Act	Act	Act (after delay)	Act (after delay)
	ARC04	Act	Act	Act	Act (after delay)	Act (after delay)

Note: The current value and delay time can be set by referring to [chapter 6.2.6](#).

**Mode 2: Zone trip**

AFR-4 can control max 4 independent zones, each sensor can be assigned to a specific zone: ARC1 corresponds to Trip1, ARC2 to Trip2, ARC3 to Trip3, and ARC4 to Trip4.

If the SW04 current judgment function is turn on, the device will trip the corresponding trip relay when an arc signal is detected and the overcurrent exceeds the set threshold.



**Relay action diagram:**

Mode	Sensor	Trip 1	Trip 2	Trip 3	Trip 4
Mode 2	ARC01	Act			
	ARC02		Act		
	ARC03			Act	
	ARC04				Act


**Note: the diagram above only shows the application example of two zones, AFR-4 can be configured to max 4 zones as needed.**

#### 4.1.2.- SW02: Turn ON/OFF master trip mode

Master trip mode, also called as upstream breaker tripping, ensures fault clearance when the local circuit breaker fails to trip. In such cases, the device sends a trip command to the upstream breaker to cut off the fault.

When the slave device detects an arc signal from ARC01 /ARC02, it will trip MT out, Trip3 / Trip4 (within 7-8ms). If the slave's Trip3 and Trip4 are not connected or fail to tripping, the slave device will only trip MT out to sending a trip signal to the master device via MT in. Upon receiving this signal, the master device will trip FT, Trip1, and Trip2 to disconnect the fault. (entire MT mode completes the action time within 14-15ms).

When any ARC03 /ARC04 detects an arc signal, FT (within 4ms), Trip1 / Trip2 (within 7-8ms) of the master and slave device will be corresponding trip. If the slave's FT, Trip1, Trip2 is not connected or tripping fails, the slave can trip MT out and send a trip signal to the master device through MT in. After receiving this signal, the master will trip FT, Trip1, Trip2 and disconnect the fault. (entire MT mode completes the action time within 14-15ms).



**Relay action diagram:**

Mode	Sensor	Fast trip	Trip 1	Trip 2	Trip 3	Trip 4	MT out
MT mode	ARC01				Act	Act	Act
	ARC02				Act	Act	Act
	ARC03	Act	Act	Act			
	ARC04	Act	Act	Act			
	MT in	Act	Act	Act			

**Note: When MT mode is enabled, both mode 1 and mode are invalid.**

**4.1.3.- SW03: Turn ON/OFF alarm function**

When the function turns on, the arc signal occurs or the current exceeds the set value, then trip the alarm signal output.

**Relay action diagram:**


Mode	Sensor	Alarm trip
Alarm mode	ARC01	Act
	ARC02	Act
	ARC03	Act
	ARC04	Act
	I>Iset	Act

**4.1.4.- SW04: Turn ON/OFF overcurrent judgment**



Before turning on the overcurrent criteria, ensure that the CT is properly connected to the I-P terminal of the device to ensure normal operation.

Turn on the overcurrent judgment means that the relay trips only when both the arc signal ( $L > L_{set}$ ) and the current value ( $I > I_{set}$ ) exceeds threshold. User can through RS485 to set the current value and delay time, details see [chapter 6.2.6](#).



**4.1.5.- SW05-08: Turn ON/OFF ARC01-04 sensor**




After connecting the ARC sensor to terminal. DIP switch SW05–08 must be turned on individually to ensure the proper operation of the ARC sensor.

## 4.2.- RS485 communication setting



### Used to set communication:


- 1-6 bits use to set communication address
- 7-8 bits use to set the baud rate




## 5.- INSTALLATION AND START-UP

### 5.1.- Dimension

W\*H\*D: 152\*105\*50mm, Din-rail mount: 35mm



Front view




Side view



## 5.2.- Terminal definition



Marked	Notes
<b>RST</b>	Reset the device
<b>I-P</b>	Current transformer input
<b>ADD</b>	Communication setting dip switch
<b>ON/OFF</b>	Arc protection function setting dip switch



No.	Marked	Notes
B1-B2	Block	External block input , for device maintenance
B3-B4	MT out	Master trip output +/-
B5-B6	MT in	External master trip input +/-
B7-B8	MT comm	Master trip communication (for communication between AFR-4 and the company's other products.)
B9-B10	RS485 A,B	Device communication interface
ARC 01-04	ARC 01-04	Arc sensor channel 01-04 input
A1-A2	FT	Fast trip relay
A3-A4 A5-A6 A7-A8 A9-A10	Trip 1-4	Arc trip relay 1-4
A11	Reserve	
A12-A14	SF	Device self-test
A15-A16	Alarm	Arc alarm output relay
A17-A19	Reserve	
A20-A22	Power	Power supply +/-, ground wire

### 5.3.- Indicator description

- **RUN** Device running normally, and flashes once per second.
- **BLOCK** When External block input, the arc protection function is disabled.
- **MT** Device is in MT (master trip) mode.
- **COMM** Device is communicating.
- **TRIP** Arc trip relay action.
- **ALARM** Device self-test abnormality/ Arc alarm action.
- **ARC01** Arc sensor 01 connected
- **ARC02** Arc sensor 02 connected
- **ARC03** Arc sensor 03 connected
- **ARC04** Arc sensor 04 connected

#### Notes:

- "Run" indicator normally flashes once per second. If the light is constantly on, means that the program is stuck during the operation. user can try shutting down and restarting.
- "Alarm" indicator stays on for the first time, it means that the device has a self-test abnormality. user can through host computer to inquiry the reason for abnormality. If the device set arc alarm output, the indicator light will also light up. user can press the reset button to reset.
- "Trip" indicator light is constantly on, means that the arc protection output a trip signal, and an arc action has occurred. After the action occurs, it is necessary to inspect the switchgear to determine whether there is combustion or damage. After confirming that there are no abnormalities, press reset button to reset the device. After resetting, can close circuit breaker again.

## 6.- COMMUNICATION INTERFACE

### 6.1.- MODBUS © Protocol

#### Modbus RTU Frame Format:

<b>Address code</b>	<b>1 BYTE</b>	Slave device address <b>1-255</b>
<b>Function code</b>	<b>1 BYTE</b>	Indicates function codes like read coils / inputs
<b>Data code</b>	<b>4 BYTE</b>	Starting address, high byte Starting address, low byte Number of registers, high byte Number of registers, low byte
<b>Error Check code</b>	<b>2 BYTE</b>	Cyclical Redundancy Check ( <b>CRC</b> )

#### Modbus Functions:

Code	Meaning	Description
<b>FUNCTION 02</b>	Read discrete inputs	Read the digital input status of device bit by bit
<b>FUNCTION 03</b>	Read input registers	Read the analog quantity of the device
<b>FUNCTION 04</b>	Read input registers	Read parameters and settings value of device
<b>FUNCTION 05</b>	Write single coil	Control CB ON/OFF and function selection
<b>FUNCTION 06</b>	Write single register	Writes a value into a single holding register.
<b>FUNCTION 10</b>	Write multiple register	Modify parameters and set values
<b>FUNCTION 13</b>	Write single register	Restore factory settings

#### Notes:

- The transmission mode of the device is RTU (remote terminal unit) mode, and the information transmission is asynchronous.
- Communication method: support RS485 communication method.
- Baud rate: 4800/9600. Default is 9600.
- Start bit=1, data bit=8, stop bit=1, parity bit=none.
- This protocol adopts the standard calculation method of MODBUS RTU CRC16, and the verification sequence is (low-high).
- Physical address setting range: 1~255.

## 6.2.- Register Map

### 6.2.1.- Read DI signal, Read only, "02H" code to read

Addr.	Bit	Data
00 00	0	General act signal
	1	General alarm signal
	2	Maintain arc
	3	MT out
	4	MT in
	5	ARC 01
	6	ARC 02
	7	ARC 03
00 01	0	ARC 04
	1	HSO output(Fast relay output)
	2	Trip 1
	3	Trip 2
	4	Trip 3
	5	Trip 4
	6	Self-test abnormality
	7	Arc alarm output
00 02	0	Communication status
	1	Overcurrent alarm
	2	
	3	
	4	
	5	
	6	
	7	
00 03	0	Mode 1/ mode 2
	1	MT mode
	2	Arc alarm ON
	3	Current criterion
	4	ARC 01 ON
	5	ARC 02 ON
	6	ARC 03 ON
	7	ARC 04 ON

**- Command format:**

**Host inquiry:**

<b>Data Format</b>	<b>Data</b>	<b>Description</b>
Address	01H	Device address: 1-99
Function code	02H	Read DI signal
Starting register H	00H	Starting register high byte
Starting register L	00H	Starting register low byte
DI signal quantity	00H XXH	DI signal quantity
CRC L	XXH	CRC check code high byte
CRC H	XXH	CRC check code low byte

**Slave response:**

<b>Data Format</b>	<b>Data</b>	<b>Description</b>
Address	01H	Device address:1-99
Function code	02H	Read DI signal
Data length	N	Total data length
Data range	-	-
CRC_L	XXH	CRC check code low byte
CRC_H	XXH	CRC check code high byte

Note:  $N = \text{input quantity}/8$ , if the remainder is not equal to 0, then  $N = N + 1$

**- Command example**

**1. Read DI Signal**

Host inquiry:

01 02 00 00 00 40 79 FA

Slave response:

01 02 08 00 00 02 01 03 00 00 00 F8 74

### 6.2.2.- Parameter query, Read only, "03H" code to read

#### Parameter list:

Addr.	Type	Byte	Description
01 00	INT	2	Device communication address, <b>Default:1</b>
01 01	INT	2	Communication serial port 1 baud rate setting: 4800,9600, <b>Default:9600</b>
01 02	INT	2	Communication serial port 2 baud rate setting: 4800,9600, <b>Default:9600</b>
01 03	INT	2	Arc judgment delay, range: 0.001-0.05s, <b>Default:0.01s</b>
01 04	INT	2	Protection current setting value: 0.05A-40.00A, <b>Default:10A</b>
01 05	INT	2	Circuit breaker failure protection current value: 0.05A-40.00A, <b>Default:1A</b>
01 06	INT	2	Circuit breaker failure protection delay time setting value: 0.01s-10.00s, <b>Default:0.30S</b>

#### - . Command format:

##### Host inquiry:

Data Format	Data	Description
Address	01H	Device address: 1-99
Function code	03H	Read input registers
Starting register H	01H	Starting register high byte
Starting register L	00H	Starting register low byte
Data length	N	Inquiry length high byte
CRC_L	XXH	CRC check code low byte
CRC_H	XXH	CRC check code high byte

##### Slave response:

Data Format	Data	Description
Address	01H	Device address
Function code	03H	Read input registers
Data length	N	Total data length
Data range	N*2	Data range
CRC_L	XXH	CRC check code low byte
CRC_H	XXH	CRC check code high byte

Note: "N" represents register numbers, and the communication address supports FF inquiry.

**- Command example**

**1. Read parameters**

Host inquiry:

01 03 01 00 00 07 05 F4

Slave response:

01 03 0E 00 01 25 80 25 80 00 01 01 2C 00 64 00 1E F8 59

**2. Read device address**

Host inquiry:

FF 03 01 00 00 01 90 28

Slave response:

FF 03 02 00 02 10 51

### 6.2.3.- Basic parameter, Read only, "04H" code to read

Addr.	Data	Type	Byte	Description
00 00	Ia	INT	2	Protection current secondary value, unit: 0.01A
00 01	Ib	INT	2	Protection current secondary value, unit: 0.01A
00 02	Ic	INT	2	Protection current secondary value, unit: 0.01A

#### - Command format:

##### Host inquiry:

Data Format	Data	Description
Address	01H	Device address: 1-99
Function code	04H	Read input registers
Starting register H	00H	Starting register high byte
Starting register L	00H	Starting register low byte
Data length	N	Data length
CRC_L	XXH	CRC check code low byte
CRC_H	XXH	CRC check code high byte

##### Slave response:

Data Format	Data	Description
Address	01H	Device address
Function code	04H	Read input registers
Data length	2*N	Total data length
Byte length	N*2	Number of bytes
CRC_L	XXH	CRC check code low byte
CRC_H	XXH	CRC check code high byte

Note: "N" represents the number of registers

#### - Command example:

##### 1. Integer type

Host inquiry:

01 04 00 80 00 03 B1 E3

Slave response:

01 04 06 01 2C 01 2C 01 2C 30 FC



## 6.2.4.- DO control, write only, "05H" code to write

### - Command example

#### 1. DO 1 action: MT out

Host inquiry: 01 05 00 01 FF 00 DD FA

Slave response: 01 05 00 01 FF 00 DD FA

#### 2. DO 2 action: Fast trip output

Host inquiry: 01 05 00 02 FF 00 2D FA

Slave response: 01 05 00 02 FF 00 2D FA

#### 3. DO 3 action: Trip 1

Host inquiry: 01 05 01 01 FF 00 DC 06

Slave response: 01 05 01 01 FF 00 DC 06

#### 4. DO 4 action: Trip 2

Host inquiry: 01 05 01 02 FF 00 2C 06

Slave response: 01 05 01 02 FF 00 2C 06

#### 5. DO 5 action: Trip 3

Host inquiry: 01 05 02 01 FF 00 DC 42

Slave response: 01 05 02 01 FF 00 DC 42

#### 6. DO 6 action: Trip 4

Host inquiry: 01 05 02 02 FF 00 2C 42

Slave response: 01 05 02 02 FF 00 2C 42

#### 7. DO 7 action: Self-test output

Host inquiry: 01 05 03 01 FF 00 DD BE

Slave response: 01 05 03 01 FF 00 DD BE

#### 8. DO 8 action: Arc alarm output

Host inquiry: 01 05 03 02 FF 00 2D BE

Slave response: 01 05 03 02 FF 00 2D BE

### 6.2.5.- DI signal reset, write only, "06H" code to write

#### - Command format:

##### Host inquiry:

Data Format	Data	Description
Address	01H	Device address: 1-99
Function code	06H	DI signal reset
Starting register H	00H	Starting register high byte
Starting register L	00H	Starting register low byte
Data length H	00H	Data length high byte
Data length L	00H	Data length low byte
CRC_L	XXH	CRC check code low byte
CRC_H	XXH	CRC check code high byte

##### Slave response:

Data Format	Data	Description
Address	01H	Device address: 1-99
Function code	06H	DI signal reset
Starting register H	00H	Starting register high byte
Starting register L	00H	Starting register low byte
Data length H	00H	Data length high byte
Data length L	00H	Data length low byte
CRC_L	XXH	CRC check code low byte
CRC_H	XXH	CRC check code high byte

#### - Command example

##### 1. Device reset

Host inquiry:

01 06 00 00 00 00 89 CA

Slave response:

01 06 00 00 00 00 89 CA

### 6.2.6.- Parameter modification, Write only, "10H" code to write

#### Parameter list:

Addr.	Type	Byte	Description
01 00	INT	2	Device communication address, <b>Default:1</b>
01 01	INT	2	Communication serial port 1 baud rate setting: 4800,9600, <b>Default:9600</b>
01 02	INT	2	Communication serial port 2 baud rate setting: 4800,9600, <b>Default:9600</b>
01 03	INT	2	Arc judgment delay, range: 0.001-0.05s, <b>Default:0.01s</b>
01 04	INT	2	Protection current setting value: 0.05A-40.00A, <b>Default:10A</b>
01 05	INT	2	Circuit breaker failure protection current value: 0.05A-40.00A, <b>Default:1A</b>
01 06	INT	2	Circuit breaker failure protection delay time setting value: 0.01s-10.00s, <b>Default:0.30S</b>

#### -. Command format:

##### Host inquiry:

Data Format	Data	Description
Address	01H	Device address: 1-99
Function code	10H	Write multiple register
Starting register H	00H	Starting register high byte
Starting register L	00H	Starting register low byte
Data length H	00H	Data length high byte
Data length L	06H	Data length low byte
Total length	2*N	Total length
Byte length	N*2	Number of bytes
CRC_L	XXH	CRC check code low byte
CRC_H	XXH	CRC check code high byte

##### Slave response:

Data Format	Data	Description
Address	01H	Device address:1-99
Function code	10H	Write multiple register
Starting register H	00H	Starting register high byte
Starting register L	00H	Starting register low byte
Data length H	00H	Data length high byte
Data length L	06H	Data length low byte
CRC_L	XXH	CRC check code low byte
CRC_H	XXH	CRC check code high byte

**- Command example**

**1. Modify parameters**

Host inquiry:

01 10 01 00 00 05 0A 00 01 00 00 25 80 25 80 00 05 01 64

Slave response:

01 10 01 00 00 05 01 F6

**6.2.7.- Restore factory settings, Write only, “13H” code to write**

**- Command format:**

**Host inquiry:**

<b>Data Format</b>	<b>Data</b>	<b>Description</b>
Address	01H	Device address
Function code	13H	Device time synchronization
Starting register H	00H	Starting register H
Starting register L	00H	Starting register L
Data length H	00H	Data length H
Data length L	00H	Data length L
CRC_L	XXH	CRC check code low byte
CRC_H	XXH	CRC check code high byte

**No slave response**

**- Command example**

Host inquiry:

01 13 00 00 00 00 84 09

No slave response

After restoring the factory settings, the device restarts and the indicator lights light up alternately.

## 7.- SAFETY CONSIDERATIONS



All installation specification described at the previous chapters named:  
**INSTALLATION AND STARTUP, INSTALLATION MODES and SPECIFICATIONS.**

Please note that with the instrument powered on, the terminals could be dangerous to touching and cover opening actions or elements removal may allow accessing dangerous parts. This instrument is factory-shipped at proper operation condition.

- ◆ The device must have a professional installation and maintenance.
- ◆ Any operation of the device, you must cut off the input signal and power.

## 8.- MAINTENANCE

The AFR-4 does not require any special maintenance. No adjustment, maintenance or repairing action should be done when the instrument is open and powered on, should those actions are essential, high-qualified operators must perform them.

Before any adjustment, replacement, maintenance or repairing operation is carried out, the instrument must be disconnected from any power supply source.

When any protection failure is suspected to exist, the instrument must be immediately put out of service. The instrument's design allows a quick replacement in case of any failure.

For any inquiry about the instrument performance or any failure, contact to Blue Jay's technical service.

*Blue Jay - After-sales service*

E-mail: [tech@cqbluejay.com](mailto:tech@cqbluejay.com)