

SETMINI

Embedded DC power system background communication protocol

Table of Contents

| | | |
|-----|---|----|
| 1 | Overview..... | 1 |
| 2 | Scope | 2 |
| 3 | Special term..... | 2 |
| 4 | Physical interface..... | 2 |
| 4.1 | Serial communication port electrical standard | 2 |
| 4.2 | Information transmission method..... | 2 |
| 5 | Communication method..... | 4 |
| 6 | Register address | 5 |
| 7 | Register data..... | 5 |
| | Appendix A | 9 |
| | Appendix B..... | 9 |
| | Appendix C..... | 10 |

1 Overview

Book « SETMINI The embedded DC power system background communication protocol (hereinafter referred to as the "Agreement") describes the protocol of the switching power supply monitoring system and its dedicated host computer-acquisition board for command control and data exchange.

2 Scope

《protocol》 The main functions specified in:

The monitoring device (ie, the master node) controls the monitoring board (ie, the slave node) to complete the specified tasks by forwarding commands, such as acquiring and setting voltage, current, and alarm limit value data.

The communication process is performed in a half-duplex, variable-length, one-way response confirmation mode, and the monitoring device sends a forwarding command and a query command to the monitoring board. Each forwarding command and query command acts as a two-way communication process. If the response fails within 50 ms after the monitoring device issues the command (address mismatch, reception timeout, received response is not acknowledgment response, received checksum is incorrect, and receive length byte is illegal), the communication fails.

3 Special term

| | |
|--------------------|---|
| Monitoring device: | A device that monitors communication to display monitoring data and set monitoring board data, and represents the master node in the master-slave protocol. |
| Monitoring board: | the display and setting module of the monitoring system, used to communicate with the monitoring device, representing the slave node in the master-slave protocol |
| RS232: | A 3-wire serial communication standard that supports full-duplex serial short-range communication |
| Query command: | sent by the monitoring device to the monitoring board to obtain the target information. |
| Setting command: | Control the monitored parameters through the monitoring device |

4 Physical interface

4.1 Serial communication port electrical standard

The monitoring board communicates with the monitoring device in RS232 half-duplex mode.

4.2 Information transmission method

Asynchronous mode, 1 start bit, 8 data bits, 1 stop bit, no parity bit.

a) Data transfer rate

9600BPS

b) Data encoding

Command using hexadecimal data

C) Read data frame format

The read command function code is 0x01, 0x02, 0x03, which supports reading the consecutive register address data once. The double-byte data is the high byte first and the low byte later.

0x01 function code read command frame format:

| | | | | | |
|-----------------|------------------------------|--------------------|------------------|--------|-----------|
| Serial number | 1 | 2 | 3 | 4 | 5 |
| Number of bytes | 1 | 1 | 2 | 2 | 2 |
| format | Communication device address | Function code 0x01 | Register address | 0x0001 | CRC check |

0x01 function code read command returns frame format:

| | | | | |
|-----------------|------------------------------|------|-----------------|-----------|
| Serial number | 1 | 2 | 3 | 4 |
| Number of bytes | 1 | 1 | 2 bytes of data | 2 |
| format | Communication device address | 0x01 | Read data | CRC check |

0x02 function code read command frame format:

| | | | | | |
|-----------------|------------------------------|--------------------|------------------|---------------------------|-----------|
| Serial number | 1 | 2 | 3 | 4 | 5 |
| Number of bytes | 1 | 1 | 2 | 2 | 2 |
| format | Communication device address | Function code 0x02 | Register address | Number of discrete data N | CRC check |

0x02 function code read command returns frame format:

| | | | | | |
|-----------------|------------------------------|------|------------------------------|------------|-----------|
| Serial number | 1 | 2 | 3 | 4 | 5 |
| Number of bytes | 1 | 1 | 1 | N% 8 bytes | 2 |
| format | Communication device address | 0x02 | The number of bytes returned | Read data | CRC check |

0x03 function code read command frame format:

| | | | | | |
|-----------------|------------------------------|--------------------|------------------|------------------------------|-----------|
| Serial number | 1 | 2 | 3 | 4 | 5 |
| Number of bytes | 1 | 1 | 2 | 2 | 2 |
| format | Communication device address | Function code 0x03 | Register address | Read the number of registers | CRC check |

0x03 function code read command returns frame format:

| | | | | | |
|-----------------|---|---|---|------------------------|---|
| Serial number | 1 | 2 | 3 | 4 | 5 |
| Number of bytes | 1 | 1 | 1 | Number of registers *2 | 2 |

| | | | | | |
|--------|------------------------------|------|--|-----------|-----------|
| format | Communication device address | 0x03 | Number of data bytes = number of read registers *2 | Read data | CRC check |
|--------|------------------------------|------|--|-----------|-----------|

d) Set the data frame format

There are three kinds of setting commands. The function codes are 0x05 and 0x06, and only one register can be set at a time. 0x10 supports setting the data of consecutive register addresses. The double-byte data is high byte first and low byte last.

Set a single register address command frame format:

| | | | | | |
|-----------------|------------------------------|----------------------------|------------------|----------------------|-----------|
| Serial number | 1 | 2 | 3 | 4 | 5 |
| Number of bytes | 1 | 1 | 2 | 2 | 2 |
| format | Communication device address | Function code (0x05, 0x06) | Register address | Set data information | CRC check |

Set the command to return. If the setting is successful, press the set command to return; otherwise, it will not return.

Set multiple register address command frame formats:

| | | | | | | | |
|-----------------|------------------------------|--------------------|------------------|-----------------------------|-------------------------|-------------------------|-----------|
| Serial number | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
| Number of bytes | 1 | 1 | 2 | 2 | 1 | Set the number of bytes | 2 |
| format | Communication device address | Function code 0x10 | Register address | Set the number of registers | Set the number of bytes | Set data information | CRC check |

Set the return data format, the setting is successful, there is a return command, the setting fails, no reply

| | | | | | |
|-----------------|------------------------------|----------------------|------------------|-------------------------|-----------|
| Serial number | 1 | 2 | 3 | 4 | 5 |
| Number of bytes | 1 | 1 | 2 | 2 | 2 |
| format | Communication device address | Function code (0x10) | Register address | Set the number of bytes | CRC check |

5 Communication method

The monitoring device and the monitoring board are in a master-slave relationship. The monitoring device is the master node and the monitoring board is the slave node. After receiving the data, the

monitoring board will parse the command and make a legal judgment on the data. If there is a problem with the format setting, the setting data is out of bounds, and the register is out of bounds, it is regarded as an illegal command, and the data is not returned. Otherwise, the data is returned in the return command format.

6 Register address

Communication device type and register range of monitoring device and monitoring board

| Issue order function code | Register address range | Number of registers | meaning |
|---------------------------|------------------------|--|--|
| 0x01 | 0x1600~0x1601 | 1 | Read state of charge |
| 0x02 | 0x0000~0x0007 | 1 byte | Read alarm information |
| | 0x1000~0x101D | 18 | Read system setup parameters |
| | 0x1100~0x110b | 6 | Reading system time |
| | 0x1200~0x120b | 6 | Read specified equalization time |
| | 0x2000~0x2019 | 13 | Reading electrical parameters |
| | 0x3000~0x30xx | Uncertain, set the number of modules * 2 | Module parameters (current, voltage) |
| 0x05 | 0x1600~0x 1601 | 1 | Equal charge floating charge setting: 0000: float charge FF00: charge status |
| 0x06 | 0x1000~0x101D | | |
| 0x10 | 0x1100~0x110b | 6 | Set system time |
| | 0x1200~0x120b | 6 | Set the charge time |

7 Register data

a) System parameter settings, please refer to Appendix C for detailed commands.

| Features | function code | Register address | Description |
|------------------------|---------------|------------------|--|
| Total module settings | 0x06 | 0x1000~0x1001 | |
| System voltage setting | 0x06 | 0x1002~0x1003 | Actual voltage value = set value / 100, Range value see note 0 |
| Charge voltage setting | 0x06 | 0x1004~0x1005 | Actual voltage value = set value / 100, Range value see note 0 |

| | | | |
|---|------|---------------|---|
| Current limit setting | 0x06 | 0x1006~0x1007 | Actual current value = set value / 100 |
| Off voltage 1 setting | 0x06 | 0x1008~0x1009 | Actual voltage value = set value / 100, Range value see note 0 |
| Reconnect voltage 1 setting | 0x06 | 0x100a~0x100b | Actual voltage value = set value / 100, Range value see note 0 |
| Off voltage 2 setting | 0x06 | 0x100c~0x100d | Actual voltage value = set value / 100, Range value see note 0 |
| Reconnect voltage 2 setting | 0x06 | 0x100e~0x100f | Actual voltage value = set value / 100, Range value see note 0 |
| Overvoltage setting | 0x06 | 0x1010~0x1011 | Actual voltage value = set value / 100, Range value see note 0 |
| Undervoltage setting | 0x06 | 0x1012~0x1013 | Actual voltage value = set value / 100, Range value see note 0 |
| Temperature compensation coefficient setting | 0x06 | 0x1014~0x1015 | |
| Temperature compensation starting point setting | 0x06 | 0x1016~0x1017 | |
| Battery temperature alarm value setting | 0x06 | 0x1018~0x1019 | Actual temperature alarm value = set value / 100 |
| Equalization time setting | 0x06 | 0x101a~0x101b | |
| Equalization interval setting | 0x06 | 0x101c~0x101d | |

b) Equal charge floating charge setting, please refer to Appendix C for detailed commands.

| Features | function code | Register address | Description |
|----------------------------|---------------|------------------|---|
| Equal charge float setting | 0x05 | 0x1600 | 0000: Floating charge FF00: Equal charge status |
| Switching machine setting | 0x05 | 0x1602 | 0000: Boot FF00: Shutdown |

c) System time and equalization time settings, please refer to Appendix C for detailed commands.

| Features | function code | Register address | Description |
|---------------------|---------------|------------------|--|
| Set system time | 0x10 | 0x1100~0x110b | Hour, minute, second, year, month, day |
| Set the charge time | 0x10 | 0x1200~0x120b | Hour, minute, second, year, month, day |

If the system time is set to match the current system time, the change command will be treated as an invalid command; if the set charge time is the same as the current charge time, the change command will be treated as an invalid command.

d) Read the charging status. For detailed commands, please refer to Appendix C.

| Features | function code | Register address | Description |
|----------|---------------|------------------|-------------|
|----------|---------------|------------------|-------------|

| | | | |
|----------------------|------|--------|---|
| Read state of charge | 0x01 | 0x1600 | 0100: Floating charge 0101: Equal charge status |
|----------------------|------|--------|---|

e) Read the alarm information. For detailed commands, please refer to Appendix C.

| Features | function code | Register address | Description |
|-------------------|---------------|------------------|-------------|
| Alarm information | 0x02 | 0x0000~0x0007 | Note 1 |

f) Read system setup parameter information. For detailed commands, please refer to Appendix C.

| Features | function code | Register address | Description |
|--|---------------|------------------|---|
| Total number of modules read | 0x03 | 0x1000~0x1001 | |
| Read system setting voltage | 0x03 | 0x1002~0x1003 | Actual voltage value = read value / 100 |
| Read equalization setting voltage | 0x03 | 0x1004~0x1005 | Actual voltage value = read value / 100 |
| Read battery current limit | 0x03 | 0x1006~0x1007 | Actual battery current limit = read value / 100 |
| Read off voltage 1 | 0x03 | 0x1008~0x1009 | Actual voltage value = read value / 100 |
| Read reconnection voltage 1 | 0x03 | 0x100a~0x100b | Actual voltage value = read value / 100 |
| Read off voltage 2 | 0x03 | 0x100c~0x100d | Actual voltage value = read value / 100 |
| Read reconnection voltage 2 | 0x03 | 0x100e~0x100f | Actual voltage value = read value / 100 |
| Read the pressure value | 0x03 | 0x1010~0x1011 | Actual voltage value = read value / 100 |
| Reading undervoltage | 0x03 | 0x1012~0x1013 | Actual voltage value = read value / 100 |
| Read temperature compensation coefficient | 0x03 | 0x1014~0x1015 | |
| Read temperature compensation starting point | 0x03 | 0x1016~0x1017 | |
| Read battery temperature alarm value | 0x03 | 0x1018~0x1019 | Actual temperature alarm value = read value / 100 |
| Read the average charge time | 0x03 | 0x101a~0x101b | |
| Read equalization interval | 0x03 | 0x101c~0x101d | |
| Read input overvoltage | 0x03 | 0x101e~0x101f | |
| Read input undervoltage | 0x03 | 0x1020~0x1021 | |
| Reading frequency | 0x03 | 0x1022~0x1023 | Actual temperature alarm value = read value / 100 |

g) Read system time and equalization time. For detailed commands, please refer to Appendix C.

| Features | function code | Register address | Description |
|----------------------------------|---------------|------------------|--|
| Reading system time | 0x03 | 0x1100~0x110b | Hour, minute, second, year, month, day |
| Read specified equalization time | 0x03 | 0x1200~0x120b | Hour, minute, second, year, month, day |

h) Read the electrical parameters. For detailed commands, please refer to Appendix C.

| Features | function code | Register address | Description |
|--------------------------|---------------|------------------|---------------------------------------|
| Read system voltage | 0x03 | 0x2000~0x2001 | Actual voltage value = read value/100 |
| Read battery current 1 | 0x03 | 0x2002~0x2003 | Actual current value = read value/100 |
| Read battery current 2 | 0x03 | 0x2004~0x2005 | Actual current value = read value/100 |
| Read module current | 0x03 | 0x2006~0x2007 | Actual current value = read value/100 |
| Read load current | 0x03 | 0x2008~0x2009 | Actual current value = read value/100 |
| Read battery temperature | 0x03 | 0x200a~0x200b | Actual temp. value = read value/100 |
| Mains 1 phase voltage | 0x03 | 0x200c~0x200d | Actual voltage value = read value/100 |
| Mains 2 phase voltage | 0x03 | 0x200e~0x200f | Actual voltage value = read value/100 |
| Mains 3-phase voltage | 0x03 | 0x2010~0x2011 | Actual voltage value = read value/100 |
| Mains frequency | 0x03 | 0x2012~0x2013 | Actual freq. value = read value/100 |
| Mains 1 phase current | 0x03 | 0x2014~0x2015 | Actual voltage value = read value/100 |
| Mains 2 phase current | 0x03 | 0x2016~0x2017 | Actual voltage value = read value/100 |
| Mains 3-phase current | 0x03 | 0x2018~0x2019 | Actual voltage value = read value/100 |

i) Read the electrical parameters. For detailed commands, please refer to Appendix C.

| Features | function code | Register address | Description |
|------------------|---------------|------------------|---|
| Module 1 current | 0x03 | 0x3000~0x3001 | Actual current value = read value/100 |
| Module 1 voltage | 0x03 | 0x3002~0x3003 | Actual temp value = read value / 100 |
| Module 2 current | 0x03 | 0x3004~0x3005 | Actual current value = read value/100 |
| Module 2 voltage | 0x03 | 0x3006~0x3007 | Actual temperature value = read value/100 |
| Module 3 current | 0x03 | 0x3008~0x3009 | Actual current value = read value/100 |
| Module 3 voltage | 0x03 | 0x300a~0x300b | Actual temp. value = read value/100 |
| Module 4 current | 0x03 | 0x300c~0x300d | Actual current value = read value/100 |
| Module 4 voltage | 0x03 | 0x300e~0x300f | Actual temp value = read value/100 |
| | | | |
| Module n current | 0x03 | | Actual current value = read value/100 |
| Module n voltage | 0x03 | | Actual temp value = read value/100 |

Note 0:

There are five series of monitoring systems: 24V, 48V, 74V, 110V, 220V

The voltage range is: 24V (18~36.5), 48V (40~59), 74V (60~83), 110V (89~152), 220V (180~300)

The limit logic of each series range is: the set value cannot be greater than the maximum value in the range, and cannot be less than the minimum value within the range. Otherwise, the monitor sets the command as an illegal command and does not reply to the data; the larger value cannot be smaller than the smaller value, for example: Overvoltage and undervoltage settings, otherwise the monitor will set the command as an illegal command and will not reply to the data; the smaller value cannot be greater than the larger value, such as reconnecting the voltage and leaving the voltage, otherwise the monitoring will be illegal according to the setting command. Command and do not reply to data.

Note 1:

0x0000 Low voltage off 1 alarm 1: Alarm 0: Normal

0x0001 Low voltage off 2 alarm 1: Alarm 0: Normal

0x0002 DC power distribution unit 1 is disconnected 1: alarm 0: normal

0x0003 DC power distribution unit 2 is disconnected 1: alarm 0: normal

0x0004 DC power distribution unit 3 is disconnected 1: Alarm 0: Normal

0x0005 DC power distribution unit 4 is disconnected 1: Alarm 0: Normal

0x0006 Battery 1 is charged and discharged 1: Alarm 0: Normal

0x0007 Mains disconnection alarm 1: Alarm 0: Normal

Appendix A


The information field is represented by 2 bytes per analog:

The analog quantity is multiplied by 100 as the information field to transmit data, with the high order byte first and the low order byte last. For example, if the current voltage of the system is 53.55V, the transmission data is 5355, and the actual transmission bytes are 0x53 and 0x55.

After the monitoring module receives and divides by 100, the actual analog data can be obtained.

Appendix B

Recommended RS485 circuit diagram and power supply method



- a. In the circuit, CON4 is the communication interface of the upper computer to the module, GND and +5V provide communication power supply for monitoring by the rectifier module, and RS585+ and RS485- are communication differential signals.
- b. GND, +5V for the host computer communication 485 power supply, TX, RX corresponding to the host computer's serial communication TTL level asynchronous transmission receiving port.
- c. RT_CTRL is the enable control signal for the host computer to control RS485 reception and transmission.

Appendix C

Command example and response analysis

| Send command function | send command | Reply command | Reply command parsing |
|------------------------------|-------------------------|---|---|
| Read state of charge | 01 01 16 00 00 01 F9 82 | 01 01 01 00 51 88 | 0100: float charge, 0101: the charge status is currently floating state |
| | | | |
| Read alarm information | 01 02 00 00 00 08 79 CC | 01 02 01 03 E1 89 | Low pressure off 1, 2 alarm |
| | | | |
| Read system setup parameters | 01 03 10 00 00 12 C1 07 | 01 03 24 00 02 14 E6 16 12 03 E8 10 CC 11 94 11 94 12 5C 17 70 10 68 00 00 00 00 0F A0 00 0A 13 88 01 2C 00 55 13 EC 06 AB | Two modules, the system setting voltage is 53.50V, the average charging voltage is 56.5V, the battery current limiting value is 10A, the decoupling voltage 1 is 43V, the reconnection voltage 1 is 45V, the decoupling voltage 2 is 45V, and the reconnection voltage 2 is 47V. The overvoltage value is 60V, the undervoltage value is 42V, the temperature compensation coefficient is 0, the temperature compensation starting point is 0, the battery temperature alarm value is 40, the equalization time is 10A, the equalization interval is 5000 hours, and the input overvoltage is 300V, input |

| | | | |
|--|-------------------------|--|--|
| | | | undervoltage 85V, frequency 51Hz, |
| Total number of modules read | 01 03 10 00 00 01 80 CA | 01 03 02 00 02 39 85 | The number of monitoring system modules is 2 |
| Read system setting voltage | 01 03 10 02 00 01 21 0A | 01 03 02 14 E6 36 CE | System voltage is 53.5V |
| Read equalization setting voltage | 01 03 10 04 00 01 C1 0B | 01 03 02 16 12 36 29 | The average charging voltage is 56.5V |
| Read battery current limit | 01 03 10 06 00 01 60 CB | 01 03 02 03 E8 B8 FA | Battery current limit is 10A |
| Read off voltage 1 | 01 03 10 08 00 01 01 08 | 01 03 02 10 CC B5 D1 | Breakaway voltage 1 is 43V |
| Read reconnection voltage 1 | 01 03 10 0A 00 01 A0 C8 | 01 03 02 11 94 B5 BB | Reconnect voltage 1 is 45V |
| Read off voltage 2 | 01 03 10 0C 00 01 40 C9 | 01 03 02 11 94 B5 BB | Breakaway voltage 2 is 45V |
| Read reconnection voltage 2 | 01 03 10 0E 00 01 E1 09 | 01 03 02 12 5C B4 DD | Reconnect voltage 2 is 47V |
| Read the pressure value | 01 03 10 10 00 01 81 0F | 01 03 02 17 70 B6 50 | Overvoltage value is 60V |
| Reading undervoltage | 01 03 10 12 00 01 20 CF | 01 03 02 10 68 B4 6A | Undervoltage is 42V |
| Read temperature compensation coefficient | 01 03 10 14 00 01 C0 CE | 01 03 02 00 00 B8 44 | Temperature compensation coefficient is 0 |
| Read temperature compensation starting point | 01 03 10 16 00 01 61 0E | 01 03 02 00 00 B8 44 | Temperature compensation starting point is 0 |
| Read battery temperature alarm value | 01 03 10 18 00 01 00 CD | 01 03 02 0F A0 BD CC | Battery temperature alarm value is 40 |
| Read the average charge time | 01 03 10 1A 00 01 A1 0D | 01 03 02 00 0A 38 43 | The charge time is 10A |
| Read equalization interval | 01 03 10 1C 00 01 41 0C | 01 03 02 13 88 B5 12 | The equalization interval is 5000 hours |
| Read input overvoltage | 01 03 10 1E 00 01 E0 CC | 01 03 02 01 2C B8 09 | Input overvoltage is 300V |
| Read input undervoltage | 01 03 10 20 00 01 81 00 | 01 03 02 00 55 78 7B | Input undervoltage is 85V |
| Read alarm frequency | 01 03 10 22 00 01 20 C0 | 01 03 02 13 EC B4 F9 | Frequency is 51Hz |
| | | | |
| Read all electrical parameters | 01 03 20 00 00 0D 8F CF | 01 03 1A 10 C1 04 B0 00 00 04 B0 04 65 0A 14 60 7C 00 00 00 00 | The system voltage is 42.89V, the battery current 1 is 12A, the battery current 2 is 0A, |

| | | | |
|---|-------------------------|---|---|
| | | 13 88 00 01 00 00 00 00 62 98 | the module current is 12A, the load current is 11.25A, the battery temperature is 25.8, the A phase voltage is 247V, the BC phase voltage is 0V, and the mains frequency is 50Hz, phase A current is 0.01A, BC phase voltage is 0A |
| Read system voltage | 01 03 20 00 00 01 8F CA | 01 03 02 10 C1 74 14 | The system voltage is 42.89V |
| Read battery current 1 | 01 03 20 02 00 01 2E 0A | 01 03 02 04 B0 BB 30 | The battery is 12A |
| Read battery current 2 | 01 03 20 04 00 01 CE 0B | 01 03 02 00 00 B8 44 | Current is 0A |
| Read module current | 01 03 20 06 00 01 6F CB | 01 03 02 04 B0 BB 30 | Current is 12A |
| Read load current | 01 03 20 08 00 01 0E 08 | 01 03 02 04 65 7A AF | Current is 11.25A |
| Read battery temperature | 01 03 20 0A 00 01 AF C8 | 01 03 02 0A 14 BE EB | Temperature is 25.8 |
| Reading the mains phase A voltage | 01 03 20 0C 00 01 4F C9 | 01 03 02 60 7C 91 A5 | Voltage is 247V |
| Reading the mains B phase voltage | 01 03 20 0E 00 01 EE 09 | 01 03 02 00 00 B8 44 | Voltage is 0 (single-phase input is not 0) |
| Reading the mains C-phase voltage | 01 03 20 10 00 01 8E 0F | 01 03 02 00 00 B8 44 | Voltage is 0 (single-phase input is not 0) |
| Reading city frequency | 01 03 20 12 00 01 2F CF | 01 03 02 13 88 B5 12 | Mains frequency is 50Hz |
| Reading the mains phase A current | 01 03 20 14 00 01 CF CE | 01 03 02 00 01 79 84 | Current is 0.01A |
| Reading the mains B phase current | 01 03 20 16 00 01 6E 0E | 01 03 02 00 00 B8 44 | Current is 0A |
| Reading the mains C phase current | 01 03 20 18 00 01 0F CD | 01 03 02 00 00 B8 44 | Current is 0A |
| | | | |
| | | | |
| Read all module information of the system of 2 modules | 01 03 30 00 00 04 4B 09 | 01 03 08 00 15 16 10 00 1C 16 0E 5C 41 | Module 1 current is 0.21A, voltage is 56.48V; module 2 current is 0.28A, voltage is 56.46V |
| Read module 1 current | 01 03 30 00 00 01 8B 0A | 01 03 02 00 1C B9 8D | Current is 0.28A |
| Read module 1 voltage | 01 03 30 02 00 01 2A CA | 01 03 02 16 10 B7 E8 | The voltage is 56.48V |
| Read module 2 | 01 03 30 04 00 01 CA CB | 01 03 02 00 15 79 8B | Current is 0.21A |

| | | | |
|--|-------------------------|-------------------------|-----------------------|
| current | | | |
| Read module 2 voltage | 01 03 30 06 00 01 6B 0B | 01 03 02 16 0E 37 E0 | The voltage is 56.46V |
| | | | |
| Set 1 module | 01 06 10 00 00 01 4C CA | 01 06 10 00 00 01 4C CA | Successful setup |
| Set the system voltage: 53.8V | 01 06 10 02 15 04 23 99 | 01 06 10 02 15 04 23 99 | Successful setup |
| Set the average charging voltage: 57.0 V | 01 06 10 04 16 44 C2 98 | 01 06 10 04 16 44 C2 98 | Successful setup |
| Set the battery current limit: 9A | 01 06 10 06 03 84 6D 98 | 01 06 10 06 03 84 6D 98 | Successful setup |
| Set the breakaway voltage 1: 42V | 01 06 10 08 10 68 00 E6 | 01 06 10 08 10 68 00 E6 | Successful setup |
| Set the reconnection voltage 1: 44V | 01 06 10 0A 11 30 A1 4C | 01 06 10 0A 11 30 A1 4C | Successful setup |
| Set the breakaway voltage 2: 44V | 01 06 10 0C 11 30 41 4D | 01 06 10 0C 11 30 41 4D | Successful setup |
| Set the reconnection voltage 2: 47V | 01 06 10 0E 12 5C E0 50 | 01 06 10 0E 12 5C E0 50 | Successful setup |
| Set the overvoltage value: 59V | 01 06 10 10 17 0C 83 3A | 01 06 10 10 17 0C 83 3A | Successful setup |
| Set the undervoltage value: 43V | 01 06 10 12 10 CC 20 9A | 01 06 10 12 10 CC 20 9A | Successful setup |
| Set the temperature compensation coefficient: 1 | 01 06 10 14 00 01 0C CE | 01 06 10 14 00 01 0C CE | Successful setup |
| Set the temperature compensation starting point: 1 | 01 06 10 16 00 01 AD 0E | 01 06 10 16 00 01 AD 0E | Successful setup |
| Set battery temperature alarm value: 42 | 01 06 10 18 10 68 01 23 | 01 06 10 18 10 68 01 23 | Successful setup |
| Set the duration of the charge: 12 | 01 06 10 1A 00 0C AC C8 | 01 06 10 1A 00 0C AC C8 | Successful setup |
| Set the | 01 06 10 1C 13 87 01 9E | 01 06 10 1C 13 87 01 9E | Successful setup |

| | | | |
|--|--|-------------------------|------------------|
| equalization interval: 4999 hours | | 9E | |
| Set the input overvoltage value: 298V | 01 06 10 1E 01 2A 6D 43 | 01 06 10 1E 01 2A 6D 43 | Successful setup |
| Set the input undervoltage value: 87V | 01 06 10 20 00 57 CD 3E | 01 06 10 20 00 57 CD 3E | Successful setup |
| Set the alarm frequency: 21Hz | 01 06 10 22 00 15 EC CF | 01 06 10 22 00 15 EC CF | Successful setup |
| | | | |
| | | | |
| Set the system time: 2017-08-28 17:36:00 | 01 10 11 00 00 06 0c 00 11 00 24 00 00 07 E1 00 08 00 1C 90 15 | 01 10 12 00 00 0C C5 74 | Successful setup |
| Set the float time: 2017-08-28 17:36:00 | 01 10 12 00 00 06 0c 00 11 00 24 00 00 07 E1 00 08 00 1C 60 E5 | 01 10 12 00 00 0C C5 74 | Successful setup |
| | | | |
| | | | |
| Set equal charge | 01 05 16 00 FF 00 88 72 | 01 05 16 00 FF 00 88 72 | Successful setup |
| Setting up the float | 01 05 16 00 00 00 C9 82 | 01 05 16 00 00 00 C9 82 | Successful setup |